

Digital Video Camera Module

Technical Manual



XCL-S600/S600C/S900/S900C

Table of Contents

Overview

Features	3
Typical CCD Phenomena	4
System Components	5
Connection	5
Location and Function of Parts and Operation	6
Front/Top/Bottom	6
Using a tripod	6
Rear	7
Connecting the cables	8

Connections

Communication Setting	9
Camera Link Tap	9
Data Order	10
1tap	10
2tap (when sensor tap is 1 or 2)	10
2tap (when sensor tap is 4)	11
Port assignment	12
Color pixel array	12
Trigger Signal Input	13
Trigger signal polarity	13
GPIO Connector	14

Functions

Partial Scan	16
Binning	16
Sensor Tap	16
Switching sensor tap	16
Level correction between sensor taps	17
Adjusting level correction between sensor taps	17
Output Bit Depth	17
Gain	17
Analog gain	17
Digital gain	17
Auto gain (AGC)	17
Shutter (Exposure)	18
Configuring the setting	18
Auto exposure (AE)	18
Combination of Continuous AGC and Continuous AE	18
Trigger Control	19
Free run/Trigger mode	19
Special trigger	20
Trigger source	21
Trigger inhibition	21
Trigger shift	22
Trigger delay	23
Trigger counter	23
Frame counter	23

Trigger range limit	23
Trigger control	24
Frame Rate	24
Auto frame rate	24
Specifying frame rate	25
Displaying frame rate	25
Fastest frame rate for partial scanning	26
Timing Chart	28
Horizontal timing	28
Vertical timing	28
Trigger latency	29
Sensor Readout (Sensor Output)	30
White Balance	31
LUT	31
Binarization	31
5-point interpolation	31
Arbitrary setting	32
Save LUT	32
Color Matrix Conversion	32
3 × 3 filter	32
3 × 3 filter	32
Test Chart Output	32
GPIO	33
GPI	33
GPO	33
Pulse Train Generator	35
Status LED	35
Temperature Readout Function	35
Defect Correction	35
Shading Correction	36
Sensitivity Control	38
User Set	38
User set name	38
User set memory	38
Free Memory	38
User ID	38
Saving and Startup	39
Initializing	39
Camera Information	39
Help Command	39
Echo off	39
Restart	39

Camera Control Commands

Command Form	40
Command Input and Response	40
Command List	41
Parameter List	48

Specifications

Specifications	49
Spectral Sensitivity Characteristics (Typical Values)	52
Dimensions	53

Overview

This unit is a digital video camera module that outputs digital images utilizing LVDS via the DIGITAL IF connector.

Features

DIGITAL IF connector

Equipped with a Camera Link standard mini connector. The unit can output a detailed and high speed digital image.

High definition and high speed image capture

The unit includes a 9,000,000-pixel or 6,000,000-pixel high-resolution CCD, with high speed read out depending on each model.

You can select 1ch, 2ch or 4ch sensor output. The frame rate depends on the channel selected.

CCD size and resolution		Monochrome model	Color model
1/1 type CCD	9 Mega	XCL-S900	XCL-S900C
1/1 type CCD	6 Mega	XCL-S600	XCL-S600C

Sensor tap	XCL-S600/S600C	
	Frame rate	Maximum output of pixels (H) × (V)
4ch	27 fps	2,758 × 2,208
2ch	13 fps	
1ch	7.5 fps	

Sensor tap	XCL-S900/S900C	
	Frame rate	Maximum output of pixels (H) × (V)
4ch	18 fps	3,388 × 2,712
2ch	9 fps	
1ch	5 fps	

The XCL-S900 and XCL-S600 monochrome models use an EXview HAD CCD II™ high sensitivity sensor, usable even in the near-infrared region.

Various settings

Sending a command from the host device allows various settings, including the following.

- Gain
- Shutter
- Partial scan
- Trigger control
- LUT (Look Up Table)
- Output: 8/10/12-bit or RGB 24-bit

- Defect correction
- Shading correction

Electronic shutter function

Set anywhere from 1/100,000 sec to 2 sec in 1 μs increments.

External trigger shutter function

By synchronizing with an external trigger signal, any shutter timing can be used.

Partial scan

The camera module can limit the number of video output lines to achieve high frame rates, enabling high-speed image processing.

Body fixing

The screw holes to install the camera module are located under the front panel (the CCD reference plane). Installing the camera module on the front panel minimizes deviation of the optical axis.

LUT (Look Up Table)

You can switch to OFF or ON. When set to OFF, you can select from five preset values, such as inversion, binarization, any of five-point approximation, etc.

Switching an Output Bit Length

You can select 8-bit output, 10-bit output, or 12-bit output.

For color models, you can also select an RGB 24-bit output.

Binning (Monochrome camera only)

Sensitivity can be doubled by combining two pixels aligned vertically, you can achieve a standard output frame rate between 1.8x and 2x. Sensitivity can be doubled by combining two pixels align horizontally. You can set horizontal and vertical binning at the same time.

Defect correction

The unit includes a function to reduce sensor defects, and can be set to ON or OFF.

Shading correction

The unit includes a function to correct shading, resulting from a light source or a particular lens, and can be set to ON or OFF.

Note

The CCD is driven at high speed during a Partial scan or Binning operation. In this situation, if intense light is input to the camera, the peripheral areas of the video image may be affected. In such a situation, adjust the amount of light using the iris.

Typical CCD Phenomena

The following effects on the monitor screen are characteristic of CCD cameras. They do not indicate any fault with the camera module.

Smear

This occurs when shooting a very bright object such as electric lighting, the sun, or a strong reflection.

This phenomenon is caused by an electric charge induced by infrared radiation deep in the photosensor. It appears as a vertical smear, since the CCD imaging element uses an interline transfer system.

Vertical aliasing

When you shoot vertical stripes or lines, they may appear jagged.

Blemishes

A CCD image sensor consists of an array of individual sensor elements (pixels). A malfunctioning sensor element will cause a single pixel blemish in the picture (This is generally not a problem.).

White speckles

While CCD image pickup device is made by an accurate technique, imperceptible speckles may rarely come up on the screen due to cosmic rays and so on. This is connected to the principle of CCD image pickup device, not a malfunction. And the white speckles are easy to come up in the following conditions.

- Using the camera in high temperature
- When turning up the gain

Note

If strong light enters a wide area of the screen, the screen may become dark. This is not a malfunction.

If this occurs, avoid strong light or adjust the lens iris to reduce the light amount.

Note on laser beams



Laser beams may damage a CCD. You are cautioned that the surface of a CCD should not be exposed to laser beam radiation in an environment where a laser beam device is used.




CCXC-12P02N (2 m, 6.6 ft)
CCXC-12P05N (5 m, 16.4 ft)
CCXC-12P10N (10 m, 32.8 ft)
CCXC-12P25N (25 m, 82 ft)



C-mount lens
Use a lens appropriate for the pixel count of the camera.




Tripod adaptor
VCT-ST70I (Insulated
type)



Install the board in a PCI bus slot in devices such as a computer. Select a commercially available interface board compatible with the Camera Link feature. You can use either a board that supports PoCL, or one that does not.

Due to the performance of the board, the frame rate may become low according to lack of processing capacity. To have this product output frames at the highest speed, use a board corresponding to PCI-Express.


Performance may also be dependent on the host device (e.g., Computer), so consult the dealer if images are not displayed properly.



This cable connects to the DIGITAL IF connector on the rear panel of the camera module. Image/control signals are transmitted via this cable.

Select a proper cable as the maximum usable length of a cable differs due to the attribute of each cable.

Spotted noise may appear in a specific brightness in the window according to the attribute of the cable. If this noise is an obstacle, shorten the cable.




Power supply

You can supply power via the DC IN connector using the power adapter. Use DC-700/700CE which is the stable power source free from ripple or noise.

Location and Function of Parts and Operation

Front/Top/Bottom



1 Lens mount (C-mount)

Attach any C-mount lens or other optical equipment.

Note

The lens must not project more than 10 mm (13/32 inch) from the lens mount.

- ① Lens mount face ② 10 mm (13/32 inch) or less

When you use the camera with the lens attached, the resolution of the image output from the camera may differ according to the performance of the lens. Note it when you select a lens.

The performance of a lens may change according to the aperture level.

If the resolution is not enough, adjust the aperture level.

2 Guide screw holes (Top)

3 LED light screw holes

Use these screw holes to attach the LED light to the camera module.

Use an adapter appropriate for the LED light as required.

4 Guide screw holes / Tripod screw holes (Bottom)

These precision screw holes are for locking the camera module. Locking the camera module into these holes secures the optical axis alignment.

When using a tripod, use these four screw holes to attach a VCT-ST70I tripod adaptor.

Note

Refer to Dimensions in page 53 for about the position/size of the Guide hole and the Reference hole.

Using a tripod

To use the tripod, install the tripod adaptor VCT-ST70I (not supplied) on the camera module.

Use a tripod screw with a protrusion (ℓ) extending from the installation surface, as follows, and tighten it, using a screwdriver. Be sure that the protrusion (ℓ) does not exceed 5.5 mm (0.22 in.) in length.

Length 4.5 to 5.5 mm


Length 0.18 to 0.22 inches



Note

If you install a tripod adapter (not supplied), use the screws (M3 × 8 (4)) provided.

Rear



5 DC IN (DC power input) connector (12-pin)

You can connect a camera cable CCXC-12P05N etc. to input the +12 V DC power supply.

For details on the pin arrangement, see the following table.

Pin No.	Signal	Pin No.	Signal
1	Ground	7	GPI3/GPO3
2	DC +12 V	8	GPI4(ISO-)
3	ISO Ground	9	GPO4(ISO)
4	GPI1/GPO1	10	GPI4(ISO+)
5	GPO2(ISO-)	11	GPI2
6	GPO2(ISO+)	12	ISO Ground

Power input

Pin 1 (Ground) and pin 2 (DC +12 V) are used.

Signal input

Pins 4, 7, 10 and 11 (GPI1/3/4/2) are used for GPI input or trigger input.

When selecting 1 system for GPI (ISO):

- GPI4 (ISO+) (pin 10) and GPI4 (ISO-) (pin 8) are used.

When selecting 2 systems for GPI:

- GPI1 (pin 4*) and Ground (pin 1) are used.
- GPI3 (pin 7*) and Ground (pin 1) are used.

* Pins 4 and 7 can switch GPI input and GPO output, by external command. The initial value is GPI.

Signal output

Pins 4, 6, 7 and 9 (GPO1/2/3/4) allow you to select GPO from the exposure signal, strobe control signal, Hi/Low fixed value, etc.

When selecting 2 systems for GPO (ISO):

- GPO4 (ISO) (pin 9) and ISO Ground (pins 3 and 12) are used.

- GPO2 (ISO+) (pin 6) and GPO2 (ISO-) (pin 5) are used.

When selecting 2 systems for GPO:

- GPO1 (pin 4*) and Ground (pin 1) are used.
- GPO3 (pin 7*) and Ground (pin 1) are used.

* The initial value of pins 4 and 7 is GPI. Switch to GPO output by external command.

6 DIGITAL IF (Interface) connector (26-pin)

You can connect a Camera Link cable to this connector to control a camera module from a host device utilizing the serial communication protocol while outputting a video signal from the camera module. You can input the external trigger signal via the DIGITAL IF connector and operate a camera module in the external trigger mode.


The following table shows the relation between the pin numbers of the DIGITAL IF connector and the input/output signals and the like.

Pin No.	Signal	Pin No.	Signal
1	Ground	14	Ground
2	X0-	15	X0+
3	X1-	16	X1+
4	X2-	17	X2+
5	XCLK-	18	XCLK+
6	X3-	19	X3+
7	SerTC+	20	SerTC-
8	SerTFG-	21	SerTFG+
9	CC1-	22	CC1+
10	CC2+	23	CC2-
11	CC3-	24	CC3+
12	CC4+	25	CC4-
13	Ground	26	Ground

7 Status LED (Green)

When power is on, this LED lights up.

Connecting the cables



Connect the camera cable to the DC IN connector and the Camera Link cable to the DIGITAL IF cable respectively. When you connect the Camera Link cable, turn the two fastening screws on the connector to secure the cable tightly.

Connect the other end of the camera cable to the DC-700/700CE and the other end of the Camera Link cable to the camera module interface board.

Note

This camera does not support PoCL. To prevent the camera from malfunction, do not supply power from the Camera Link board.

Controlling the camera from the host device

You can control the camera from host device such as a computer. The following table shows the major control functions.

You can send a command corresponding to the control items, with parameters for the desired settings, if necessary, from the host device to control the camera. Refer to “Camera Control Commands” on page 40 for details on how to send a command, the commands, and their parameters.

Control functions	Description	
Operating mode	Free run/Trigger	
Shutter speed	Free run	1/100,000 sec to 2 sec
	Trigger edge detection	1/100,000 sec to 2 sec
	Trigger pulse width detection	Setting by trigger pulse width
Gain	0 dB to 18 dB	
Partial Scan	Variable, 4-line increments	
LUT (Look Up Table)	OFF/ON (Mode: 5 types)	
External trigger input	DIGITAL IF connector/DC IN connector	
Video output switch	Monochrome model: Mono 8/10/12-bit Color model: Raw 8/10/12-bit, RGB 24-bit	
Binning (Monochrome camera only)	2 × 1, 1 × 2, 2 × 2	
Defect correction	OFF/ON	
Shading correction	OFF/ON	

Note

Make sure to supply power to the camera module and confirm that the camera module is operating before inputting a trigger signal. If you input trigger signal to a camera module without the power supplied, this may cause a malfunction of the camera module.

Image at partial scan

Depending on the image input board of the camera you are using, if settings for the boards received image size and the image size output from a camera do not conform, picture noise or sync issues may occur.

Communication Setting

The serial port assigned to the camera link board is used. The communication system is an asynchronous method compliant with RS-232C. The following table shows the transmission control specifications. Command inputs are echoed back. Inputs are not case-sensitive.

Baud rate	115200/57600/ <u>38400</u> /19200/9600 [bps]
Data bit	8
Parity	None
Stop bit	1
Flow control	None

Default values are underlined. (same applies hereinafter)


Camera Link Tap

1tap output or 2tap output can be selected, regardless of the camera settings. Output clock frequencies are as follows. Lowering the output clock frequency improves the tolerance to video signal attenuation, which allows the camera link cable length to be extended. Thus, it is recommended to use with 2tap unless there are board restrictions. Only the selection of sensor tap1 or 2, or camera link tap1 is available for RGB24-bit output. The output of sensor tap4 is only available for the selection of camera link tap2.


Sensor Tap Command SENSOR-TAP	Camera Link Tap Command CAMERALINK-TAP	
	1	<u>2</u>
1	available Clock 54 MHz	available Clock 27 MHz
2	available Clock 84 MHz	available Clock 42 MHz
<u>4</u>	unavailable	available <u>Clock 84 MHz</u>

Data Order


Figures below show the data order when an image of $M \times N$ pixels is transmitted in camera link tap1 and camera link tap2.




1tap



2tap (when sensor tap is 1 or 2)



2tap (when sensor tap is 4)



* The order of the lines output is as follows:

For D1 (upper half of the screen), the order is from Line 1 to Line $N/2$.

For D2 (lower half of the screen), the order is from Line N to Line $N/2 + 1$.

Trigger Signal Input

Trigger signals can be input via the 4th/7th/10th/11th pins of the DC IN connector, the CC1, CC2, CC3, CC4 pins of the Digital IF connector, or the software command. Switchover of the trigger signal can be changed via the TRG-SRC command.

command	param	Trigger signal assigned pin
TRG-SRC	4	DC IN connector 4th pin*
	7	DC IN connector 7th pin*
	10	DC IN connector 10th pin
	11	DC IN connector 11th pin
	101	Digital IF connector 22nd [+] / 9th [-] (CC1)
	102	Digital IF connector 10th [+] / 23th [-] (CC2)
	103	Digital IF connector 24th [+] / 11th [-] (CC3)
	104	Digital IF connector 12nd [+] / 25th [-] (CC4)
	0	Software command (TRG-SOFT)
	20	OR of DC IN connector 4th/7th/10th/11th pin

* DC IN connector 4th pin and 7th pin are available only when the GPIO input/output setting is switched to input.

Trigger signal polarity

Positive refers to a trigger signal polarity activated while rising from Low to Hi, or during the Hi interval. Negative refers to a trigger signal polarity activated while falling from Hi to Low, or during the Low interval. The default value of a camera is Negative.

Use the 11th pin to input a trigger signal

The DC IN connector 11th pin is pulled up on the camera side. When a connector is open, the trigger signal is at the high level and is logically inactive. Note that when Positive of DC IN connector 11th pin is selected as a trigger input, when the terminal is open, the trigger will be activated.

Use the 4th or 7th pin to input a trigger signal


When input is via the 11th pin, the high level value varies between 2 V to 24 V and 3.5 V to 5.5 V. Low level value is 0 V to 0.4 V.

Use the 10th (ISO+) or 8th (ISO-) pin to input a trigger signal


When input is via the 11th pin, the high level value varies between 2 V to 24 V and 5 V to 24 V. Low level value is 0 V to 0.4 V.

command	param	Trigger signal polarity
TRG-POL	0	Negative
	1	Positive

DC IN connector specifications




Trigger input polarity = Negative



Note

When inputting a trigger signal to the camera using the DC-700, use DC 5 V or less at the logical high level.


Digital IF connector specifications




GPIO Connector

The DC IN connector's 10th and 11th pins are for the GPI connector, the 6th and 9th pins are for the GPO (+) connector, the 4th and 7th pins are for the GPIO switching connector. The trigger reset connector is the DC IN connector 11th pin. If you are connecting an external device to each connector, refer to the circuit specifications below.


GPI circuit specifications



GPO circuit specifications




GPIO input (10th pin ISO)



Example

Input voltage [V]	TDF [ns]	FT [ns]	TDR [ns]	RT [ns]
5.0	167	297	192	358

GPIO output (6th pin ISO or 9th pin ISO)




* Rising the input signal as soon as possible.

Example

When connecting to an external power supply, be sure to use a pull-up resistor for a current limit of less than 50 mA.

	Supply voltage of the output [V]	Pull-up resistor Use 1/16 W	Current [mA]	TDF [μs]	FT [μs]	TDR [μs]	RT [μs]	Output voltage [V]
Normal temperature	3.3	470 Ω	5.07	0.75	0.49	24	35	0.916
	5.0	820 Ω	4.98	0.73	0.63	28	46	0.909
	12.0	Two 2200 Ω resistors in parallel	9.87	0.71	1.05	36	64	1.112
	24.0	Eight 8200 Ω resistors in parallel	21.85	0.73	1.45	45	76	1.571



Partial Scan

Only the area selected from the effective pixel area can be read out. Clearing unnecessary parts at high-speed allows high-speed reading. The area size is selected by the HEIGHT and WIDTH commands, and the read beginning point is selected by the OFFSETX and OFFSETY commands. Using the ROI command, you can set HEIGHT, WIDTH, OFFSETX and OFFSETY at the same time. Reducing HEIGHT increases the frame rate, but changing WIDTH does not change the frame rate. Partial scan can be set with or without a trigger. Binning can be used at the same time.

OFFSETX and OFFSETY relate to WIDTH and HEIGHT as follows:

$\text{OFFSETX} + \text{WIDTH} \leq \text{WIDTH (maximum value)}$

$\text{OFFSETY} + \text{HEIGHT} \leq \text{HEIGHT (maximum value)}$

When selecting sensor tap4, a central line divides the screen into two halves symmetrically for a vertical division. For the relationship between OFFSETY and HEIGHT, see the following formula:

$\text{OFFSETY} \times 2 + \text{HEIGHT} = \text{Maximum lines}$

(For XCL-S600 the maximum number of lines is 2208, for XCL-S900 the maximum number of lines is 2712)

Because the value of OFFSET is set automatically by HEIGHT and the maximum number of lines, the command to change OFFSETY is not available.

(Example of XCL-S900)

>SENSOR-TAP 4

>HEIGHT 480 → HEIGHT is 480, OFFSETY is set to 1116 (= (2712 - 480) ÷ 2)

>OFFSETY 0 → OFFSETY change not available.

Note

Since the shutter setting has priority, use a shutter speed high enough to enable partial scan at a higher frame rate.


Configurable range

	WIDTH	HEIGHT
XCL-S600/S600C	16 ~ 2758	4 ~ 2208
XCL-S900/S900C	16 ~ 3388	4 ~ 2712

Configurable values

OFFSETX, WIDTH: 2-step increments

OFFSETY, HEIGHT: 4-step increments



command	param1	param2	param3	param4
ROI	Width	Height	OffsetX	OffsetY

Binning

By adding 2 vertical pixels or 2 horizontal pixels, the frame rate in vertical binning is increased along with the sensitivity. The color camera cannot set this. This can be set with or without a trigger. Partial scan can be used concurrently and horizontal and vertical can be set at the same time.

command	param	Setting
VBIN	1	No binning
	2	Vertical binning
HBIN	1	No binning
	2	Horizontal binning

Sensor Tap

Switching sensor tap

This unit has a CCD with 4-channel output which is available for 4-channel, 2-channel and 1-channel reading. The reading speed becomes faster as the value of the channel number increases.

command	param	Setting
SENSOR TAP	1	1-channel
	2	2-channel
	<u>4</u>	<u>4-channel</u>

Level correction between sensor taps

Since XCL-S600/S600C and XCL-S900/S900C have a CCD with 4-channel signal outputs, output level differences may occur during channel reading due to the characteristic difference between channels. Level correction between sensor taps can correct the level differences. A command for one-push (automatically detecting the level difference and adjusting only once), continuous (constantly detecting the level difference and adjusting continuously), and manual correction (correcting left and right manually) is provided. After one-push is performed once, the state returns to manual designation.

command	param	Setting
BLACKLEV EL-AUTO- BALANCE (BL-AB)	<u>0</u>	<u>Manual designation</u>
	1	One-push (only once)
	2	Continuous (consecutive)

Manual designation is performed by the BL-ADJ-1/2 command. The left screen is for TAP1 and the right screen is for TAP2. One push and continuous commands automatically set the value for TAP2.

command	param	Setting
BL-ADJ-1	-255 to <u>0</u> to 255	Black level correction value for left screen
BL-ADJ-2	-255 to <u>0</u> to 255	Black level correction value for right screen

Adjusting level correction between sensor taps

The one-push command should be executed after setting the output level to all black by removing light sources. When One-push or Continuous is performed as taking an image normally, the shade difference of an object is detected as the level difference between taps and level correction may not work properly on rare occasions. In this case, the limit value (BL-AB-LIMIT) should be adjusted so that the level is automatically adjusted to the proper value. Lowering the value allows preventing excessive detection but interferes the normal level correction between taps to work properly. The level should be adjusted accordingly since the optimal value differs depending on the environment (such as an object and light source) and camera settings (such as gain and shutter).

command	param	Setting
BL-AB-LIMIT	1 to <u>512</u> to 16383	Setting lower value prevents excessive detection

Output Bit Depth

Monochrome cameras can switch between 8 bits, 10 bits, and 12 bits. Color cameras can switch between Raw output 8 bits, 10 bits, 12 bits, and RGB output 24 bits.

command	param	Setting
PIXEL-DEPTH	<u>8</u> /10/12/24	24 is only for color camera

Gain

Analog gain

The analog gain can be set finely in 1 dB unit or bit level (up to 18 dB). It can be set per the sensor tap as well.

command	param	Setting
GAIN	<u>0</u> to 18	Gain dB unit (full screen)
GAIN-TAP1	<u>0</u> to 18	Gain dB unit (left screen)
GAIN-TAP2	<u>0</u> to 18	Gain dB unit (right screen)
GAIN-FINE	<u>0</u> to 512	Gain advanced setting (full screen)
GAIN-FINE-TAP1	<u>0</u> to 512	Gain advanced setting (left screen)
GAIN-FINE-TAP2	<u>0</u> to 512	Gain advanced setting (right screen)

Digital gain


The digital gain is not implemented in this device.

Auto gain (AGC)

By executing the GAIN-AUTO command, the gain is automatically adjusted according to the image pickup environment. AGC works so that the average level in a detection frame may reach AGC-LEVEL. The AGC detection frame is set to the central region by default. The detection frame can be displayed or the detection area changed.

command	param	Setting
GAIN-AUTO (AGC)	<u>0</u>	<u>Manual gain</u>
	1	One-push AGC
	2	Continuous AGC
AGC-LEVEL	0 to <u>11264</u> to <u>16383</u>	AGC target level (14 bit)
AGC-SPEED	1 to <u>256</u>	AGC convergence speed
AGC-UPPER	0 to <u>18</u>	AGC upper limit (dB)
AGC-LOWER	<u>0</u> to 18	AGC lower limit (dB)
AGC-FRAME-HIGHLIGHT	<u>0</u>	AGC detection frame is <u>hidden</u>
	1	AGC detection frame is displayed

command	param1	param2	param3	param4
AGC-FRAME	1 to 100	1 to 100	0 to 99	0 to 99



Shutter (Exposure)

Configuring the setting

The setting is configured in μs unit. During free run operation, the frame rate is reduced by setting a value bigger than the default shutter value.

command	param
EXP	10 to 2000000

	EXP [μs]	Rate [fps]
XCL-S600/S600C	<u>37000</u>	27
XCL-S900/S900C	<u>55000</u>	18


Auto exposure (AE)

The shutter is set automatically by detecting the output level. The target level is the same as the value of AGC-LEVEL. This can be performed along with auto gain.

command	param	Setting
EXPOSURE-AUTO (AE)	<u>0</u>	<u>Manual shutter</u>
	1	One-push AE
	2	Continuous AE
AE-SPEED	1 to <u>192</u> to 256	AE convergence speed
AE-UPPER	10 to 2000000	AE upper limit
AE-LOWER	10 to 2000000	AE lower limit

Combination of Continuous AGC and Continuous AE

AGC and AE coordinate with each other to adjust the level automatically with AGC-LEVEL as the target level. When the environment starts getting dark and the shutter is released, AGC starts to work.



Trigger Control

Free run/Trigger mode

Free run

The camera operates without a trigger signal and performs the video output operation continuously after the shutter (exposure) is finished. The horizontal and vertical timing signals are generated within the camera. During the free-run operation, image pickup timing cannot be controlled. In the free-run operation, the adjustment is made automatically to achieve the maximum frame rate according to the shutter setting.

Trigger mode

Exposure is started by detecting the externally input trigger signal. When EXP-MODE is 0, exposure is started by detecting the rising or falling edge of the trigger signal and the trigger edge detection (exposure is performed based on the set shutter value) is performed. When EXP-MODE is 1, the trigger width detection (exposed for the period of the trigger signal width) is performed.


command	param	Setting
TRG-MODE	<u>0</u>	Free run
	1	Trigger mode

For trigger mode (TRG-MODE=1)

command	param	Setting
EXP-MODE	<u>0</u>	Trigger edge detection
	1	Trigger width detection


Trigger edge detection

The figure shows the trigger signal negative polarity (detecting the drop edge).



Trigger width detection

The figure shows the trigger signal negative polarity (detecting Low level width).



Special trigger

When operating in trigger mode and performing image pickup in different conditions (such as the shutter, gain, and image pickup area), the setting has to be changed in advance for each trigger input. However, if the special trigger operation is enabled, the setting does not have to be changed and continuous image pick up in different conditions is facilitated. Up to 16 settings can be configured. There are the bulk operations in which images are taken consecutively by inputting the trigger signal once and the sequential operation in which images are taken each time the trigger signal is detected. The next exposure is started after the end of video output. In the sequential operation, the second and subsequent trigger signals should be input 5 ms or more after the end of video output. During the special trigger operation, the device cannot be entered to the trigger mode. The source and polarity of the special trigger signal should be defined separately from the trigger mode. Each setting should be saved in the user set. For the items reflected, refer to “Command List” (page 41).

Note

During special trigger operation, defect correction cannot be used.

command	param	Setting
SP-TRG-MODE	<u>0</u>	<u>Special trigger off</u>
	1	Bulk
	2	Sequential


command	param	Setting
SP-TRG-SRC	4	DC IN connector 4th pin*
	7	DC IN connector 7th pin*
	10	DC IN connector 10th pin
	<u>11</u>	<u>DC IN connector 11th pin</u>
	101	Digital IF connector 22nd [+] / 9th [-] (CC1)
	102	Digital IF connector 10th [+] / 23rd [-] (CC2)
	103	Digital IF connector 24th [+] / 11st [-] (CC3)
	104	Digital IF connector 12nd [+] / 25th [-] (CC4)
	0	Software command (TRG-SOFT)
	20	OR of DC IN connector 4th/7th/10th/11th pin

* DC IN connector 4th pin and 7th pin are available only when the GPIO input/output setting is switched to input.

command	param	Setting
SP-TRG-POL	<u>0</u>	<u>Negative</u>
	1	Positive


Bulk

SP-TRG-MODE=1, SP-TRG-POL=0, SP-TRG-F-CNT=3 in the figure.




Sequential

SP-TRG-MODE=2, SP-TRG-POL=0, SP-TRG-F-CNT=3 in the figure.



Trigger states




Trigger source

This can be input via the DC IN connector, Digital IF connector, or software command (TRG-SOFT). Refer to “Trigger Signal Input” (page 13) for details. Note that the trigger sources for the special trigger operation and the trigger mode operation are defined separately.

Trigger inhibition


Trigger input can be disabled. This function is effective when disabling the trigger signal to a specific camera in the environment where multiple cameras are connected by the same trigger signal and when preventing false operations caused by noise contamination to the trigger signal line (due to the installed environment).



command	param	Setting
TRG-INH	0	Trigger is accepted
	1	Trigger is not accepted


Trigger shift

This device can accept exposure by the next trigger even while a video is output (except for the special trigger operation). In this case, trigger shift should be enabled since the trigger signal can become a noise source. When trigger shift is enabled, adjustment is made automatically for operations from trigger input to exposure to prevent noise contamination. Therefore, the time from trigger input to exposure start will be delayed up to 1 line. When disabling trigger shift, this delay adjustment is not made and exposure is started consistently at the constant timing but noise may occur in the image. Even when the trigger shift is enabled, the next video cannot be output before completing video output and the trigger is disabled. Therefore, the exposure time setting (in the trigger edge operation), the effective period of the trigger signal width to be input (in the trigger width operation), or the trigger interval should be sufficiently long.




When the next image can be output

Since video output is completed after the exposure is finished, the next video output can be started.



When the next image cannot be output (double exposure)


Since video output is not completed after the exposure is finished, the next video output cannot be started. The input trigger becomes invalid.



Trigger delay

The camera can delay the trigger signal.

When a trigger signal is input before the trigger delay time, or a trigger which contains noise is recognized, the image cannot be displayed. This is not a malfunction.



command	param	Setting
TRG-DLY	<u>0</u> to 4000000	Trigger delay [μ s]

Trigger counter

Accepted triggers by which video output is performed are counted. Triggers are counted up by the internal counter even in the free-run operation. Setting 0 resets the counter. Video output is not performed for triggers that coincide with the double exposure timing, but triggers are counted up. Triggers that have been removed by trigger range limit are not counted. The trigger counter returns to 0 when the upper limit (2147483647) is reached.

command
TRG-CNT

Frame counter

The frame counter increases when an image is output. Setting 0 resets the counter. Frames whose image cannot be output due to triggers that coincide with the double exposure timing are not counted. The trigger counter returns to 0 when the upper limit (2147483647) is reached.

command
FRAME-COUNTER


Trigger range limit

Only signals in the set trigger width can be accepted as the trigger signal. This functions as a noise filter, which removes chattering or disturbance noise in the trigger signal line. This also functions as a trigger selector, whereby only a specific camera can be operated by the trigger when multiple cameras share one trigger signal line. When the trigger signal is input, exposure is started immediately to increment the trigger counter; however, when trigger width is out of the range, video is not output and the trigger counter is decremented. If the shutter time is set shorter than the upper limit, triggers will be received and video is output even if the trigger signal is wider than the trigger range limit. If the trigger source is soft trigger, trigger range is not enabled.


command	param	Setting
TRG-RANGE	<u>0</u>	Trigger range off
	1	Trigger range on
TRG-RANGE-LOWER	<u>10</u> to 2000000	Trigger range lower limit [μ s]
TRG-RANGE-UPPER	10 to <u>2000000</u>	Trigger range upper limit [μ s]

Trigger range operation example

EXP=300, TRG-RANGE-LOWER=100, TRG-RANGE-UPPER=200 in the figure.



EXP=300, TRG-RANGE-LOWER=100, TRG-RANGE-UPPER=1000 in the figure.



Trigger control

Since detection of the trigger width time requires a certain time during the trigger width detection operation, the exposure time will be slightly longer than the input trigger width time. To perfectly match with the trigger signal width period, TRG-CTRL should be set to 0. TRG-SHIFT=1 and TRG-CTRL=0 cannot be set at the same time. Refer to "Trigger latency" (page 29) for details.

Frame Rate

Auto frame rate

The reading cycle is set to allow the frame rate to be the maximum value automatically according to the current shutter setting and the partial scan setting in the free-run operation (Shutter has priority). The next exposure is performed while outputting a video and the next video output is started immediately after finishing all video outputs. The frame rate is lowered when setting the shutter time longer than the video output time.

command	param	Setting
FRAMERATE-AUTO	0	Off
	<u>1</u>	<u>On</u>

Specifying frame rate

The frame rate of the video output can be specified in the free-run operation. The value of the frame rate [fps] × 1,000,000 should be entered. The frame rate faster than the fastest frame rate cannot be set.

command	param
FRAMERATE	62500 to *

* The upper limit varies depending on the partial scan setting.

Example for setting 15 [fps]: FRAMERATE 15000000

Displaying frame rate


The current frame rate during the auto frame rate operation is displayed.

command
FRAMERATE-ACTUAL


Fastest frame rate for partial scanning

The fastest frame rate varies depending on HEIGHT for partial scanning.


XCL-S600/C (sensor-tap=4)




XCL-S600/C (sensor-tap=2)




XCL-S600/C (sensor-tap=1)




XCL-S900/C (sensor-tap=4)



XCL-S900/C (sensor-tap=2)




XCL-S900/C (sensor-tap=1)



Timing Chart

Horizontal timing


Constant regardless of the trigger mode, binning, and partial scanning. DVAL and LVAL are the same signal.



	sensor-tap	STROBE	A	B
XCL-S600/C	1	54 MHz	3184*	WIDTH*
	2	84 MHz	2772*	WIDTH*
	4	84 MHz	2772	WIDTH
XCL-S900/C	1	54 MHz	3872*	WIDTH*
	2	84 MHz	3402*	WIDTH*
	4	84 MHz	3402	WIDTH

* When CAMERALINK-TAP=1. The value will be half during 2tap output.
Start time is shifted according to the OFFSETX value.

Vertical timing




	sensor-tap	C	D	n
XCL-S600/C	1	24 + OFFSETX	3184 - WIDTH - C	HEIGHT
	2	13 + OFFSETX	2772 - WIDTH - C	HEIGHT
	4	13 + OFFSETX	2772 - WIDTH - C	HEIGHT / 2
XCL-S900/C	1	24 + OFFSETX	3872 - WIDTH - C	HEIGHT
	2	13 + OFFSETX	3402 - WIDTH - C	HEIGHT
	4	13 + OFFSETX	3402 - WIDTH - C	HEIGHT / 2

E: Varies depending on the EXP, OFFSETY value or trigger latency.

Trigger latency

The time from the trigger acceptance to the exposure start (trigger latency) varies depending on various conditions. In the trigger width detection operation, the value is changed by TRG-CTRL.



XCL-S600/S600C (for channel 2 and channel 4)

EXP-MODE	TRG-CTRL	TRG-SHIFT	Trigger latency	Exposure time
0 (edge detection)		0	Approx. 1.5 μ s	EXP
		1	Approx. 1.5 μ s to 34.5 μ s	EXP
1 (width detection)	0	0	Approx. 10.6 μ s	EXP
		1	Cannot be set	
	1	0	Approx. 1.6 μ s	EXP + 9.1 μ s
		1	Approx. 1.6 μ s to 34.6 μ s	EXP + 9.1 μ s

XCL-S600/S600C (for channel 1)

EXP-MODE	TRG-CTRL	TRG-SHIFT	Trigger latency	Exposure time
0 (edge detection)		0	Approx. 1.5 μ s	EXP
		1	Approx. 1.5 μ s to 60.4 μ s	EXP
1 (width detection)	0	0	Approx. 10.6 μ s	EXP
		1	Cannot be set	
	1	0	Approx. 1.6 μ s	EXP + 9.1 μ s
		1	Approx. 1.6 μ s to 60.5 μ s	EXP + 9.1 μ s

XCL-S900/S900C (for channel 2 and channel 4)


EXP-MODE	TRG-CTRL	TRG-SHIFT	Trigger latency	Exposure time
0 (edge detection)		0	Approx. 1.2 μ s	EXP
		1	Approx. 1.2 μ s to 41.7 μ s	EXP
1 (width detection)	0	0	Approx. 52.8 μ s	EXP
		1	Cannot be set	
	1	0	Approx. 1.3 μ s	EXP + 51.6 μ s
		1	Approx. 1.3 μ s to 41.8 μ s	EXP + 51.6 μ s

XCL-S900/S900C (for channel 1)

EXP-MODE	TRG-CTRL	TRG-SHIFT	Trigger latency	Exposure time
0 (edge detection)		0	Approx. 1.2 μ s	EXP
		1	Approx. 1.2 μ s to 72.9 μ s	EXP
1 (width detection)	0	0	Approx. 52.8 μ s	EXP
		1	Cannot be set	
	1	0	Approx. 1.3 μ s	EXP + 51.6 μ s
		1	Approx. 1.3 μ s to 73.0 μ s	EXP + 51.6 μ s

Sensor Readout (Sensor Output)

This signal indicates that exposure has completed and the CCD has entered the video output sequence. Output is available from the DC IN connector 4th/6th/7th/9th pin. The sensor readout signal is asserted before optical black and the effective pixel area is output. If the following trigger signal is input when this signal is asserted, horizontal line noise may occur in an image. The trigger shift function (page 22) can effectively prevent noise contamination. The time required for the CCD to start OB (optical black) and effective pixel output after sensor readout signal assertion is shown below. Moreover, when the CCD starts picture signal output, picture signals such as FVAL take at least as much time as is required for 4 to 4.5 lines. OB is not output from a camera.



	sensor-tap	F	G*
XCL-S600/C	1	Approx. 172 μ s	Approx. 254 μ s
	2,4	Approx. 95 μ s	Approx. 150 μ s
XCL-S900/C	1	Approx. 170 μ s	Approx. 306 μ s
	2,4	Approx. 157 μ s	Approx. 182 μ s

* When OFFSETX= 0, OFFSETY= 0, shortest value.

White Balance

The white balance can be automatically adjusted once when the WHITEBALANCE-AUTO command is executed. The detection area is set to the screen center by default. The detection area can also be displayed on the screen. The detection frame can be changed arbitrarily (AWB-FRAME). For manual correction, the FINE command should be executed. The white balance can be set finely per sensor tap. Therefore, a fine adjustment should be made if the color difference between sensor taps cannot be adjusted completely by AWB.

command	param	Setting
WHITEBALANCE-AUTO (AWB)	<u>0</u>	Manual correction
	1	One-push AWB
AWB-FRAME-HIGHLIGHT	<u>0</u>	Detection frame is hidden
	1	Detection frame is displayed

command	param	Setting
RGAIN-FINE	<u>256 (×1)</u> to 4095	Red gain
GGAIN-FINE	<u>256 (×1)</u> to 4095	Green gain
BGAIN-FINE	<u>256 (×1)</u> to 4095	Blue gain


For reference

If the color offset between the left and right sensor taps cannot be cleared through fine adjustment using the FINE command, adjustment of the black level may work. Set the R, G, and B FINE levels to ×1 (256), align the black levels, and then use the FINE command to make fine adjustments. This tends to occur in low temperature environments and when analog gain is set high.

LUT

Five types of presets are provided. Specify using a 12 bit value. Binarization, 5-point interpolation, and arbitrary setting can be changed.

command	param	Setting
LUT-FORMAT	<u>0</u>	<u>LUT off ($\gamma=1$)</u>
	1	Reverse
	2	Binarization
	3	5-point interpolation
	4	Arbitrary setting



Binarization

The binarization threshold can be changed.


command	param
BINARIZATION	0 to <u>2047</u> to 4095

5-point interpolation

The values of output points 1 through 5 that correspond to input points 1 through 5 can be changed. Linear interpolation is performed between interpolation points.

command	param1	param2	param3
LINEAR-INTERPOLATION	1 to 5	0 to 4095	0 to 4095

Setting example:



```
>LINEAR-INTERPOLATION 1 240 200
>LINEAR-INTERPOLATION 2 900 400
>LINEAR-INTERPOLATION 3 2047 3000
>LINEAR-INTERPOLATION 4 3000 3200
>LINEAR-INTERPOLATION 5 3800 3900
>LINEAR-INTERPOLATION-BUILD
>LUT-FORMAT 3
```

Arbitrary setting

The output values 0 through 4095 that correspond to input values 0 through 4095 can be changed.

command	param1	param2
LUT	0 to 4095	0 to 4095

Setting example:

```
>LUT 0 3
>LUT 1 10
>LUT 2 20
...
>LUT 4094 4000
>LUT 4095 4010
>LUT-FORMAT 3
```

Save LUT

When you change the settings, save them using the LUT-SAVE command.

command
LUT-SAVE

Color Matrix Conversion

During RGB output, the following color matrix conversion can be applied to the color model. Specify using values between -8191 and 8191. 256 is $\times 1$.

$$\begin{bmatrix} R \\ G \\ B \end{bmatrix} = \begin{bmatrix} Gain00 & Gain01 & Gain02 \\ Gain10 & Gain11 & Gain12 \\ Gain20 & Gain21 & Gain22 \end{bmatrix} \begin{bmatrix} R \\ G \\ B \end{bmatrix}$$

command	param	Setting
CR-TF	<u>0</u>	<u>Conversion off</u>
	1	Conversion on

command	param1	param2	Setting
CR-TF-VAL	00	-8191 to <u>256</u> to 8191	Gain00
	01	-8191 to <u>0</u> to 8191	Gain01
	02	-8191 to <u>0</u> to 8191	Gain02
	10	-8191 to <u>0</u> to 8191	Gain10
	11	-8191 to <u>256</u> to 8191	Gain11
	12	-8191 to <u>0</u> to 8191	Gain12
	20	-8191 to <u>0</u> to 8191	Gain20
	21	-8191 to <u>0</u> to 8191	Gain21
	22	-8191 to <u>256</u> to 8191	Gain22

3 × 3 filter

The nine filter parameters can be set from -8191 to 8191. The parameter 256 is $\times 1$.

Depending on the patterns of parameters, you can reduce noise, apply edge enhancement and extract the contour.

3 × 3 filter

Monochrome model and color model apply a 3 × 3 area filter for RAW output. The brightness of the central pixel and the eight pixels around it, and the parameter of each pixel are multiplied and added together. The result is the brightness of the central pixels. Specify using values between -8191 and 8191. The parameter 256 is $\times 1$.

command	param	Setting
SP-FL	0	filter off
	1	filter on

command	param1	param2	Setting
SP-FL-VAL	00	-8191 ~ 8191	Parameter for the upper left pixel
	01	-8191 ~ 8191	Parameter for the upper pixel
	02	-8191 ~ 8191	Parameter for the upper right pixel
	10	-8191 ~ 8191	Parameter for the left pixel
	11	-8191 ~ 8191	Parameter for the central pixel
	12	-8191 ~ 8191	Parameter for the right pixel
	20	-8191 ~ 8191	Parameter for the lower left pixel
	21	-8191 ~ 8191	Parameter for the lower pixel
	22	-8191 ~ 8191	Parameter for the lower right pixel

Test Chart Output

For monochrome model, monochrome chart can be set. For color model, monochrome chart or color chart can be set.

command	param	Setting
TESTCHAR T	<u>0</u>	<u>Off</u>
	1	Monochrome chart
	2	Color chart

①	②	③	④	⑤	⑥	⑦
---	---	---	---	---	---	---

	Monochrome	Color		
	Raw/Mono	R	G	B
(1)	0xF30	0x3FF	0x3FF	0x3FF
(2)	0xDC0	0x3FF	0x3FF	0
(3)	0xC80	0	0x3FF	0x3FF
(4)	0xA00	0	0x3FF	0
(5)	0x7A0	0x3FF	0	0x3FF
(6)	0x550	0x3FF	0	0
(7)	0x340	0	0	0x3FF

* 12 bit notation

command	param1	param2	Setting
GPO-SRC	4/6/7/9*	0	Exposure signal
		1	Strobe control signal
		2	LVAL signal
		3	FVAL signal
		4	Sensor readout signal
		5	Trigger through signal
		6	Pulse generation signal
		<u>7</u>	<u>User definition 1</u>
		8	User definition 2
		9	User definition 3
		10	User definition 4

* DC IN connector 4th pin and 7th pin are available only when the GPIO input/output setting is switched to input.

command	param	Setting
GPO-INVERTER	0	Without signal inversion
	<u>1</u>	<u>With signal inversion</u>

Setting example:

LVAL signal is output to GPO2 (DC IN connector 6th pin), Hi active setting (Hi is enabled)

>GPO-SRC 6 2

>GPO-INVERTER 6 0

GPIO

GPI


The value can be checked by detecting the signals input to the DC IN connector 4th, 7th, 10th, and 11th using the GPI command. Since 11th pin is pulled up, 1 (Hi level) is returned if they are opened.

command	param
GPI	4/7/10/11

GPO


GPO output can be transmitted from the DC IN connector 4th, 6th, 7th and 9th pins. After selecting a signal, the output polarity should be determined by GPO-INVERTER. The strobe control signal can be set separately for the DC IN connector 4th, 6th, 7th and 9th pins.

GPO output system diagram (example of DC IN connector 9th pin)



Factory Setting


The following chart shows the factory setting for DC IN connector 9th pin. User-defined 1 is also set to the other GPO connectors (Hi output).



Pulse Train Generator

Pulse waveforms can be output from the DC IN connector 4th/6th/7th/9th pin. Available range is 0.5Hz to 100kHz.

command	param
PULSE-DUTY	1 to 2000000 [μ s]
PULSE-CYCLE	10 to 2000000 [μ s]



Status LED

LED on the rear panel lights up according to the output specification set for DC IN connector 4th/6th/7th/9th pin. Various settings are possible such as assigning the trigger signal and pulse train generator. The setting is saved immediately and reflected at the next startup.

command	param	Setting
LED-MODE	0	Off
	<u>1</u>	<u>On</u>
	2	Exposure signal synchronizing
	3	Sensor readout signal synchronizing
	4	Trigger through signal synchronizing
	5	Pulse generation signal synchronizing
	6	LVAL signal synchronizing
	7	FVAL signal synchronizing

Temperature Readout Function

The camera's internal temperature can be read from the temperature sensor installed in the circuit board. Its accuracy is $\pm 2^{\circ}\text{C}$. Use this value as a general guide.

command
TEMPERATURE


Defect Correction

It corrects clear defect points and opaque defect points which increase under the high/low temperature or when exposed for a long time (seconds). From the peripheral pixels, correction is performed on coordinate pixels in which defects are detected. Factory setting and user setting can be selected.


command	param	Setting
DEFECT-CORRECTION	<u>0</u>	<u>Correction off</u>
	1	Correction on

Defect correction setup procedure

- Set conditions in which clear defect points are prone to occur. Below is an example in which gain is 18 dB and the shutter is 1 second. Prevent as much light as possible from entering such as by blocking light.
>GAIN 18
>EXP 1000000
- Set the threshold in units of 14 bits. Points are detected as clear defect points when this level is exceeded. Below is an example for 3200 step/14bit. Pixels that indicate 3200 to 16383 are detected.
>DEFECT-THRESHOLD 3200
- Execute clear defect point detection. Detection takes four times the EXP time setting. The output levels on the same x coordinate axis are shown below. The levels uniformly indicate around 1000 steps when an all-black image is taken, but defect pixels (at high levels) are present in some locations. All pixels whose levels exceed 3200 steps, which was set in step 2, are detected.
>DEFECT-DETECTION 1




- 4** Execute opaque defect point detection. Like the clear defect point detection, set the image pickup conditions and the threshold in units of 14 bits. Below is an example for 10000 step/14bit. Pixels that indicate 0 to 10000 steps are detected. If are not setting opaque defect points, you can skip this step.
- ```
>DETECT-THRESHOLD 10000
>DETECT-DETECTION 2
```



- 5** Select the data for applying defect correction. To apply the pixels detected in steps 3 and 4, select 2. To apply factory settings, select 0. To apply values that have been saved, select 1.
- ```
>DETECT-PATTERN-LOAD 2
```

command	param	Setting
DETECT-PATTERN-LOAD	0	Factory setting
	1	User setting
	2	Data detected using DETECT-DETECTION

- 6** Turn on defect detection correction.
- ```
>DETECT-CORRECTION 1
```



- 7** Save the settings. To repeat defect detection without saving, repeat steps 1 to 6.
- ```
>DETECT-PATTERN-SAVE
```

Note

The upper limit of defect detection points is 2047 for clear and opaque defect points combined. Correction cannot be performed over the upper limit. The detected defect points can be confirmed using DETECT-DETECTION-RESULT. If the upper limit is exceeded, defect detection will fail or abnormal defect detection will occur and RESULT will be -1.

Shading Correction

Depending on the characteristics of the lens, shadings caused by a drop in the amount of light around the lens, or light source variation, are corrected. For XCL-S600/S600C, six individual user settings can be saved. For XCL-S900/S900C, ten individual user settings can be saved.

Shading Correction has two modes. In peak detection mode, you can adjust the screen to brightest level. In average detection mode, you can adjust the whole screen to its average brightness.

command	param	Function
SHADING-DETECTION	1	Start detection (peak detection)
	2	Start detection (average detection)


command	param	Function
SHADING-CORRECTION	0	Correction off
	1	Correction on

command	param	Function
SHADING-PATTERN-SAVE	0 ~ 9 (S600/S600C)	Save shading data
	0 ~ 5 (S900/S900C)	


command	param	Function
SHADING-PATTERN-SAVE	0 ~ 10 (S600/S600C)	Read shading data
	0 ~ 6 (S900/S900C)	

Shading detection setup procedure

- 1 As shown in the figure below, assume an environment in which the brightness is not uniform due to an uneven light source. Shading correction adjusts the brightness levels taking the brightest level to be the target level. Fix the lens and lighting conditions.



- 2 Adjust the exposure time and other parameters so that the target level is about 50%. On color cameras, adjust the white balance.



- 3 Execute shading detection.
 >SHADING-DETECTION 1
 Read the Status to determine whether the calculation is finished.
 >SHADING-DETECTION
 1 (running)
 2 (finished)
 Return to 0 when finished.


- 4 Determine the effect of shading correction
 >SHADING-CORRECTION 1
 >SHADING-PATTERN-LOAD 10 (for XCL-S600/S600C)
 >SHADING-PATTERN-LOAD 6 (for XCL-S900/S900C)
 Parameters 10 and 6 are available only after detecting an operation, and will not be available when the power is off.

- 5 Save the shading data
 >SHADING-PATTERN-SAVE 0


- 6 Readout the saved pattern
 >SHADING-PATTERN-LOAD 0

Note

Keep the trigger mode off when doing the shading detection. Reset the camera once if the shading correction cannot be finished.



Peak detection mode:
 The whole object tends to become brighter.



Average detection mode:
 The bright parts of the object may darken.

Sensitivity Control

The VSUB (substrate bias voltage) in the CCD can be changed. VSUB adjustment allows you to change the Qs (saturation signal charge) value. Increasing the VSUB has the effect of improving the sensitivity^{*1}. Therefore, when capturing a dark image but the exposure time cannot be extended, this has the effect of improving the image quality. On the other hand, decreasing the VSUB has the effect of reducing image smearing. The factory setting is adjusted to the optimal value.

^{*1} If Qs exceeds the maximum signal charge amount that can be transferred vertically and horizontally, a transfer error will occur, resulting in image smearing, etc.

command	param	Setting
VSUB-EXTERNAL-MODE	0	Sensitivity adjustment off
	1	Sensitivity adjustment on

command	param	Setting
VSUB-EXTERNAL	0 to 127	Sensitivity adjustment value

User Set

Main set values can be saved to the channels 1 to 16 of USERSET. Refer to “Command List” (page 41) for items to be saved. The factory setting is saved to channel 0, which cannot be overwritten.

Setting example (1):

Shutter 3 ms, Gain 3 dB, FVAL signal is output to GPO3 connector (This setting is saved to the channel 1.)
 >EXPOSURE 3000
 >GAIN 3
 >GPO 9 3
 >USERSET-SAVE 1

Setting example (2):

The user set saved in the channel 2 is loaded.
 >USERSET-LOAD 2

User set name


Strings that are 31 characters long can be assigned to channels 0 to 16. For example, you can assign names such as “setting1” and “setting2” in accordance with the settings.

command	param
USERSET-NAME	31 characters of your choice

User set memory

This is one of the items to be saved in the user set channel. Signed 32-bit numbers are assigned to slots 0 to 15.

Configuration diagram of user set



Free Memory

Signed 32-bit numbers can be saved and loaded to 8192 areas.

command	param1	param2
FREE-MEMORY	0 to 8191	-2^{31} to $2^{31} - 1$

User ID

User IDs are unique names that can be assigned to cameras. A string that is 15 characters long can be assigned.

command	param
USER-ID	15 characters of your choice

Saving and Startup

The startup setting can be determined by USERSET-DEFAULT. This is also used to check which user set settings are currently being used.

Usage example:

Startup with the setting saved in the user set channel 3.
>USERSET-DEFAULT 3
(Restart or RESET command)

Check which user set settings are the current settings.
>USERSET-DEFAULT
0
OK

Initializing

In the user settings, all settings, such as unsaved baud rate settings can be returned to the factory defaults. For details on initialized items, refer to “Command List” (page 41).

command
FACTORY-DEFAULT

Camera Information

The model name of a camera or its firmware information can be read out.

command	Read out items
VENDOR	Manufacture name (SONY)
MODEL	Model name
VERSION	Firmware version
ID	Serial number
MANUFACTURER	Data for service

Help Command

To display the command list, execute HELP. To display the details of a command, add HELP in front of the command and execute.

Setting example:

Check about GAIN.
>HELP GAIN
GAIN:
Controls the analog gain (in dB).
This can take the value in following range:
min:0, max:18, step:1
OK

Echo off

Echo back of the command is not available.
Set to echo off when you want to speed up the communication response.

command	param	Function
ECHO	0	Excluding echo back
	<u>1</u>	<u>Including echo back</u>

Restart

The camera is rebooted.

command
RESET

Command Form

When inputting commands, separate a command and a parameter by a space, and press [Enter] to confirm. Upper/lower case characters are not distinguished. Input format and an input example are shown below.

Input format:

Command Param1 param2 param3 Param4 [Enter]

Input example:

ROI 640 480 8 6 <CR>

Command Input and Response

Camera echoes back against characters (alphabetic, numeric), space, backspace and Enter; otherwise, other invalid characters are ignored. When a command is successfully completed, the status will be echoed.

Input: Gain 6<CR>

Output: OK<CR>

Status	Explanation (Example)
OK	Successfully completed
ERROR: Invalid argument number.	The argument number of the parameter is invalid. (Width 100 100)
ERROR: Invalid parameter.	The parameter is invalid. (Width abc)
ERROR: Not implemented.	The command is not supported. (Vbin of a color camera)
ERROR: Access denied.	Commands are limited. (A trigger mode related command is controlled by SP-TRG-MODE=1.)
ERROR: Busy	The command cannot be received.
SYNTAX ERROR!	The command is not correct. (Width 100)

Command List

Save	Camera	This item is saved in a different area to the user set.
	UserSet	This item is saved in the user set from 1-16.
Load	SpecialTrigger	This item is set in the special trigger mode.
	UserSet	This item is set with the UserSet-load command.
Reset	Reset	This item is initialized if a reset or reboot command is executed.
	FactoryDefault	This item is initialized if a Factory-Default command is executed.

	Command	Parameter 1	Parameter 2	Parameter 3	Parameter 4	Camera		UserSet	SpecialTrigger	Load	UserSet	Reset	FactoryDefault
						Save	Reset						
VENDOR		-	-	-	-	-	-	-	-	-	-	-	-
MODEL		-	-	-	-	-	-	-	-	-	-	-	-
MANUFACTURER		-	-	-	-	-	-	-	-	-	-	-	-
VERSION		-	-	-	-	-	-	-	-	-	-	-	-
ID		-	-	-	-	-	-	-	-	-	-	-	-
USER-ID		15 characters	-	-	-	○	-	-	-	-	-	-	○
USER-ID-DELETE		-	-	-	-	-	-	-	-	-	-	-	-
RESET		-	-	-	-	-	-	-	-	-	-	-	-
TEMPERATURE		-	-	-	-	-	-	-	-	-	-	-	-
BAUDRATE		9600 / 14400 / 19200 38400 / 57600 / 115200	-	-	-	○	-	-	-	-	-	-	○
LED-MODE		0 / 1 / 2 / 3 / 4 / 5 / 6 / 7	-	-	-	○	-	-	-	-	-	-	○
VSUB-EXTERNAL-MODE *1		0 / 1	-	-	-	-	○	-	-	○	-	-	○
VSUB-EXTERNAL *1		0 ~ 127	-	-	-	-	○	-	-	○	-	-	○
SENSOR-WIDTH		-	-	-	-	-	-	-	-	-	-	-	-
SENSOR-HEIGHT		-	-	-	-	-	-	-	-	-	-	-	-
SENSOR-TAP *1		1 / 2 / 4	-	-	-	-	○	-	-	○	-	-	○
ROI *1		16 ~ : Width	4 ~ : Height	0 ~ : OffsetX	0 ~ : OffsetY	-	○	-	-	○	-	-	○
WIDTH *1		16 ~	-	-	-	-	○	-	-	○	-	-	○
HEIGHT *1		4 ~	-	-	-	-	○	-	-	○	-	-	○



Command	Parameter 1	Parameter 2	Parameter 3	Parameter 4	Camera		SpecialTrigger	Load	UserSet	Reset	FactoryDefault
					Save	UserSet					
OFFSETX *1	0 ~	-	-	-	-	-	○	○	○	-	○
OFFSEY *1	0 ~	-	-	-	-	-	○	○	○	-	○
HBINNING / HBIN	$\frac{1}{2}$	-	-	-	-	-	○	○	○	-	○
VBINNING / VBIN	$\frac{1}{2}$	-	-	-	-	-	○	○	○	-	○
PIXEL-DEPTH	$\frac{8}{10 / 12 / 24}$	-	-	-	-	-	○	○	○	-	○
CAMERALINK-TAP	$\frac{1}{2}$	-	-	-	-	-	○	○	○	-	○
TESTCHART	$\frac{0}{1 / 2}$	-	-	-	-	-	-	-	-	○	○
FRAMERATE *1	62500 ~*2	-	-	-	-	-	○	○	○	-	○
FRAMERATE-AUTO	$\frac{0}{1}$	-	-	-	-	-	○	○	○	-	○
FRAMERATE-ACTUAL	-	-	-	-	-	-	-	-	-	-	-
SPECIAL-TRIGGER-MODE / SP-TRG-MODE	$\frac{0}{1 / 2}$	-	-	-	-	-	-	-	-	○	○
SPECIAL-TRIGGER-FRAMECOUNT / SP-TRG-F-CNT	$1 \sim \frac{2}{16}$	-	-	-	-	-	○	○	○	-	○
SPECIAL-TRIGGER-SOURCE / SP-TRG-SRC	$\frac{0}{7 / 10 / 11 / 20 / 101 / 102 / 103 / 104}$	-	-	-	-	-	○	○	○	-	○
SPECIAL-TRIGGER-POLARITY / SP-TRG-POL	$\frac{0}{1}$	-	-	-	-	-	○	○	○	-	○
TRIGGER-MODE / TRG-MODE	$\frac{0}{1}$	-	-	-	-	-	○	○	○	-	○
TRIGGER-SOURCE / TRG-SRC	$\frac{0}{7 / 10 / 11 / 20 / 101 / 102 / 103 / 104}$	-	-	-	-	-	○	○	○	-	○
TRIGGER-INHIBIT / TRG-INH	$\frac{0}{1}$	-	-	-	-	-	○	○	○	-	○
TRIGGER-POLARITY / TRG-POL	$\frac{0}{1}$	-	-	-	-	-	○	○	○	-	○
TRIGGER-SHIFT / TRG-SHIFT	$\frac{0}{1}$	-	-	-	-	-	○	○	○	-	○
TRIGGER-CONTROL / TRG-CTRL	$\frac{0}{1}$	-	-	-	-	-	○	○	○	-	○
TRIGGER-DELAY / TRG-DLY	$\frac{0}{\sim 4000000}$	-	-	-	-	-	○	○	○	-	○
TRIGGER-SOFTWARE / TRG-SOFT	$\frac{0}{1}$	-	-	-	-	-	-	-	-	-	-
TRIGGER-RANGE / TRG-RANGE	$\frac{0}{1}$	-	-	-	-	-	○	○	○	-	○

Command	Parameter 1	Parameter 2	Parameter 3	Parameter 4	Camera		UserSet	SpecialTrigger	Load	Reset		FactoryDefault
					Save	Reset						
TRIGGER-RANGE-UPPERLIMIT / TRG-RANGE-UPPER	10 ~ 2000000	-	-	-	-	-	○	-	○	-	○	○
TRIGGER-RANGE-LOWERLIMIT / TRG-RANGE-LOWER	10 ~ 2000000	-	-	-	-	-	○	-	○	-	○	○
EXPOSURE-MODE / EXP-MODE	0 / 1	-	-	-	-	-	○	-	○	-	○	○
EXPOSURE / EXP *1	10 ~ 2000000	-	-	-	-	-	○	○	○	-	○	○
EXPOSURE-AUTO / AE	0 / 1 / 2	-	-	-	-	-	○	-	○	-	○	○
EXPOSURE-AUTO-SPEED / AE-SPEED	1 ~ 192 ~ 256	-	-	-	-	-	○	-	○	-	○	○
EXPOSURE-AUTO-UPPERLIMIT / AE-UPPER *1	S600/S600C: 10 ~ 37000 S900/S900C: 10 ~ 55000	-	-	-	-	-	○	-	○	-	○	○
EXPOSURE-AUTO-LOWERLIMIT / AE-LOWER	10 ~ 2000000	-	-	-	-	-	○	-	○	-	○	○
GPIO-MODE	4 / 7	0 / 1	-	-	-	-	○	○	○	-	○	○
GPO-INVERTER / GPO-INV *3	4 / 6 / 7 / 9	0 / 1	-	-	-	-	○	○	○	-	○	○
GPI *3	4 / 7 / 10 / 11	-	-	-	-	-	-	-	-	-	-	-
GPO-SOURCE / GPO-SRC	4 / 6 / 7 / 9	0 / 1 / 2 / 3 / 4 / 5 / 6 / 7 / 8 / 9	-	-	-	-	○	○	○	-	○	○
STROBE-TIME / STRB-TIME	4 / 6 / 9	1 ~ 256 ~ 4000	-	-	-	-	○	○	○	-	○	○
STROBE-DELAY / STRB-DLY	4 / 6 / 9	0 ~ 100 ~ 4000	-	-	-	-	○	○	○	-	○	○
USER-OUTPUT	1 / 2 / 3	0 / 1	-	-	-	-	○	○	○	-	○	○
PULSE-CYCLE	10 ~ 1000000 ~ 2000000	-	-	-	-	-	○	○	○	-	○	○
PULSE-DUTY	1 ~ 500000 ~ 2000000	-	-	-	-	-	○	○	○	-	○	○
TRIGGER-COUNTER / TRG-CNT	- (0 : Reset)	-	-	-	-	-	-	-	-	-	○	○
FRAME-COUNTER	- (0 : Reset)	-	-	-	-	-	-	-	-	-	○	○

Command	Parameter 1	Parameter 2	Parameter 3	Parameter 4	Camera		UserSet	SpecialTrigger	Load	UserSet	Reset	FactoryDefault
					Save	Reset						
GAIN	0 ~ 18	-	-	-	-	-	-	-	-	-	-	-
GAIN-TAP1												
GAIN-TAP2												
GAIN-TAP3												
GAIN-TAP4												
GAIN-FINE	0 ~ 502	-	-	-	-	-	-	-	-	-	-	-
GAIN-FINE-TAP1												
GAIN-FINE-TAP2												
GAIN-FINE-TAP3												
GAIN-FINE-TAP4												
GAIN-AUTO / AGC	0 / 1 / 2	-	-	-	-	-	-	-	-	-	-	-
GAIN-AUTO-LEVEL / AGC-LEVEL	0 ~ 11264 ~ 16383	-	-	-	-	-	-	-	-	-	-	-
GAIN-AUTO-SPEED / AGC-SPEED	1 ~ 256	-	-	-	-	-	-	-	-	-	-	-
GAIN-AUTO-UPPERLIMIT / AGC-UPPER	0 ~ 18	-	-	-	-	-	-	-	-	-	-	-
GAIN-AUTO-LOWERLIMIT / AGC-LOWER	0 ~ 18	-	-	-	-	-	-	-	-	-	-	-
GAIN-AUTO-FRAME-HIGHLIGHT / AGC-FRAME-HIGHLIGHT	0 / 1	-	-	-	-	-	-	-	-	-	-	-
GAIN-AUTO-FRAME / AGC-FRAME	1 ~ 50 ~ 100 : Width	1 ~ 50 ~ 100 : Height	0 ~ 25 ~ 99 : OffsetX	0 ~ 25 ~ 99 : OffsetY	-	-	-	-	-	-	-	-
GAIN-AUTO-WIDTH / AGC-WIDTH	1 ~ 50 ~ 100	-	-	-	-	-	-	-	-	-	-	-
GAIN-AUTO-HEIGHT / AGC-HEIGHT	1 ~ 50 ~ 100	-	-	-	-	-	-	-	-	-	-	-
GAIN-AUTO-OFFSETX / AGC-OFFSETX	0 ~ 25 ~ 99	-	-	-	-	-	-	-	-	-	-	-
GAIN-AUTO-OFFSETY / AGC-OFFSETY	0 ~ 25 ~ 99	-	-	-	-	-	-	-	-	-	-	-

Command	Parameter 1	Parameter 2	Parameter 3	Parameter 4	Camera		UserSet	SpecialTrigger	Load	Reset		FactoryDefault
					Save	Reset						
GAIN-RED-FINE / RGAIN-FINE GAIN-RED-FINE-TAP1 /RGAIN-FINE-TAP1 GAIN-RED-FINE-TAP2 /RGAIN-FINE-TAP2 GAIN-RED-FINE-TAP3 /RGAIN-FINE-TAP3 GAIN-RED-FINE-TAP4 /RGAIN-FINE-TAP4	256 ~ <u>*2</u> ~ 4095	-	-	-	-	-	○	○	○	-	○	
GAIN-GREEN-FINE / GGAIN-FINE GAIN-GREEN-FINE-TAP1 /GGAIN-FINE-TAP1 GAIN-GREEN-FINE-TAP2 /GGAIN-FINE-TAP2 GAIN-GREEN-FINE-TAP3 /GGAIN-FINE-TAP3 GAIN-GREEN-FINE-TAP4 /GGAIN-FINE-TAP4	256 ~ <u>*2</u> ~ 4095	-	-	-	-	-	○	○	○	-	○	
GAIN-BLUE-FINE / BGAIn-FINE GAIN-BLUE-FINE-TAP1 /BGAIN-FINE-TAP1 GAIN-BLUE-FINE-TAP2 /BGAIN-FINE-TAP2 GAIN-BLUE-FINE-TAP3 /BGAIN-FINE-TAP3 GAIN-BLUE-FINE-TAP4 /BGAIN-FINE-TAP4	256 ~ <u>*2</u> ~ 4095	-	-	-	-	-	○	○	○	-	○	
WHITEBALANCE-AUTO / AWB	<u>0</u> : Off 1 : On	-	-	-	-	-	-	-	-	○	○	○
WHITEBALANCE-FRAME- HIGHLIGHT / AWB-FRAME-HIGHLIGHT	<u>0</u> : Off 1 : On	-	-	-	-	-	-	-	-	○	○	○
WHITEBALANCE-FRAME / AWB-FRAME	1 ~ <u>50</u> ~ 100 : Width	1 ~ <u>50</u> ~ 100 : Height	0 ~ <u>25</u> ~ 99 : OffsetX	0 ~ <u>25</u> ~ 99 : OffsetY	-	-	○	-	○	-	○	○
WHITEBALANCE-FRAME-WIDTH / AWB-WIDTH	1 ~ <u>50</u> ~ 100	-	-	-	-	-	○	-	○	-	○	○

Command	Parameter 1	Parameter 2	Parameter 3	Parameter 4	Camera		UserSet	SpecialTrigger	Load	Reset		FactoryDefault
					Save	Reset				UserSet	Reset	
WHITEBALANCE-FRAME-HEIGHT / AWB-HEIGHT	1 ~ 50 ~ 100	-	-	-	-	-	○	-	○	-	○	○
WHITEBALANCE-FRAME-OFFSETX / AWB-OFFSETX	0 ~ 25 ~ 99	-	-	-	-	-	○	-	○	-	-	○
WHITEBALANCE-FRAME-OFFSETY / AWB-OFFSETY	0 ~ 25 ~ 99	-	-	-	-	-	○	-	○	-	-	○
BLACKLEVEL / BL *1	~ 2047	-	-	-	-	-	○	○	○	-	-	○
BLACKLEVEL-ADJUST-TAP1 / BL-ADI-1	-255 ~ 0 ~ +255	-	-	-	-	-	○	○	○	-	-	○
BLACKLEVEL-ADJUST-TAP2 / BL-ADI-2												
BLACKLEVEL-AUTO-BALANCE / BL-AB	0 / 1 / 2	-	-	-	-	-	○	-	○	-	-	○
BLACKLEVEL-AUTO-BALANCE- LIMIT	1 ~ 512 ~ 16383	-	-	-	-	-	○	-	○	-	-	○
BL-AB-LIMIT												
LUT-FORMAT	0 / 1 / 2 / 3 / 4	-	-	-	-	-	○	○	○	-	-	○
LINEAR-INTERPOLATION	1 ~ 5 : point	0 ~ 4095 : In Value	0~4095;Out Value	-	○	-	-	-	-	-	-	○
LINEAR-INTERPOLATION-BUILD	-	-	-	-	-	-	-	-	-	-	-	-
LUT	0 ~ 4095 : Index	0 ~ 4095 : Value	-	-	○	-	-	-	-	-	-	○
LUT-SAVE	-	-	-	-	-	-	-	-	-	-	-	-
BINARIZATION	0 ~ 2047 ~ 4095	-	-	-	-	-	○	○	○	-	-	○
USERSET-LOAD	0 ~ 16	-	-	-	-	-	-	-	-	-	-	-
USERSET-SAVE	1 ~ 16	-	-	-	-	-	-	-	-	-	-	-
FACTORY-DEFAULT	-	-	-	-	-	-	-	-	-	-	-	-
USERSET-DEFAULT	0 ~ 16	-	-	-	-	-	-	-	-	-	-	-
USERSET-NAME	31 characters	-	-	-	-	-	○	○	○	-	-	○
USERSET-NAME-DELETE	-	-	-	-	-	-	-	-	-	-	-	-
USERSET-MEMORY	0 ~ 15 : Index	0 : Value	-	-	-	-	○	○	○	-	-	○

Command	Parameter 1	Parameter 2	Parameter 3	Parameter 4	Camera UserSet	SpecialTrigger	Load	UserSet	Reset	FactoryDefault
COLOR-TRANSFORMATION / CR-TF	0 / 1	-	-	-	-	○	○	○	-	○
COLOR-TRANSFORMATION-VALUE / CR-TF-VAL	00 / 01 / 02 10 / 11 / 12 20 / 21 / 22	-8191 ~ +8191	-	-	-	○	○	○	-	○
SPATIAL-FILTER/SP-FL	0 / 1	-	-	-	-	○	○	○	-	○
SPATIAL-FILTER-VALUE/SP-FL-VAL	00 / 01 / 02 10 / 11 / 12 20 / 21 / 22	-8191 ~ +8191	-	-	-	○	○	○	-	○
SHADING-CORRECTION	0 / 1	-	-	-	-	○	○	○	-	○
SHADING-DETECTION	0 / 1 / 2	-	-	-	-	-	-	-	-	-
SHADING-PATTERN-LOAD	0 / 1 / 2 / 3 / 4	-	-	-	-	○	○	○	-	○
SHADING-PATTERN-SAVE	0 / 1 / 2 / 3	-	-	-	-	-	-	-	-	-
DEFECT-CORRECTION	0 / 1	-	-	-	-	○	○	○	-	○
DEFECT-DETECTION	0 / 1 / 2	-	-	-	-	-	-	-	-	-
DEFECT-PATTERN-LOAD	0 / 1 / 2	-	-	-	-	○	○	○	-	○
DEFECT-PATTERN-SAVE	-	-	-	-	-	-	-	-	-	-
DEFECT-THRESHOLD	0 ~ 8192 ~ 16383	-	-	-	○	-	-	-	○	○
DEFECT-DETECTION-RESULT	-1 ~ 0 ~ 2047	-	-	-	-	-	-	-	-	-
FREE-MEMORY	0~(32Kbyte / 4) : Index	0 : Value	-	-	○	-	-	-	-	○
FREE-MEMORY-READ	0 ~ 8191 : Index	1~(8192 - Index) : Size	-	-	-	-	-	-	-	-
FREE-MEMORY-SAVE	-	-	-	-	-	-	-	-	-	-
VISIBILITY	1 / 2 / 3	-	-	-	-	-	-	-	○	○
ECHO	0/1	-	-	-	-	-	-	-	-	-
HELP	-(Each command)	-	-	-	-	-	-	-	-	-

*1 For the factory setting, refer to the Parameter List. (page 48)

*2 The factory setting differs for each camera.

*3 Depending on the GPIO-MODE, you can select 4th and 7th pin as an input or an output.

Parameter List

		XCL-S600/S600C	XCL-S900/S900C
VSUB-EXTERNAL-MODE		<u>0</u> : Off 1 : On	<u>0</u> : Off 1 : On
VSUB-EXTERNAL		<u>80</u>	<u>80</u>
SENSOR-TAP		1: 1ch 2: 2ch <u>4: 4ch</u>	1: 1ch 2: 2ch <u>4: 4ch</u>
ROI	Width	16 ~ <u>2752</u> ~ 2758	16 ~ <u>3384</u> ~ 3388
	Height	4 ~ <u>2200</u> ~ 2208	4 ~ <u>2704</u> ~ 2712
	OffsetX	0 ~ <u>4</u> ~ (2758 - Width)	0 ~ <u>4</u> ~ (3388 - Width)
	OffsetY	0 ~ <u>4</u> ~ (2208 - Height)	0 ~ <u>4</u> ~ (2712 - Height)
Width		16 ~ <u>2752</u> ~ 2758	16 ~ <u>3384</u> ~ 3388
Height		2 ~ <u>2200</u> ~ 2208	480 ~ <u>2704</u> ~ 2712
OffsetX		0 ~ <u>4</u> ~ (2758 - Width)	0 ~ <u>4</u> ~ (3388 - Width)
OffsetY		0 ~ <u>4</u> ~ (2208 - Height)	0 ~ <u>4</u> ~ (2712 - Height)
FRAMERATE		62500~27000000~*2	62500~180000000~*2
EXP		10 ~ <u>37000</u> ~ 2000000	10 ~ <u>55000</u> ~ 2000000
AE-UPPER		10 ~ <u>37000</u> ~ 2000000	10 ~ <u>55000</u> ~ 2000000
BLACKLEVEL		*1 ~ <u>960</u> ~ 2047	*1 ~ <u>960</u> ~ 2047

*1 The factory setting differs for each camera.

*2 The upper limit depends on the partial scan setting.

Specifications

Monochrome model

		XCL-S600	XCL-S900
Camera			
Picture size		6 megabytes	9 megabytes
Video output		1/1 type PS IT CCD	1/1 type PS IT CCD
Valid pixels (H × V)		2,758 × 2,208	3,388 × 2,712
Cell size (H × V)		4.54 μm × 4.54 μm	3.69 μm × 3.69 μm
Standard video output pixels (H × V)		2,752 × 2,200	3,384 × 2,704
color filter		—	—
Standard frame rate		27 fps (for 4-channel sensor output) 13 fps(for 2-channel sensor output) 7.5 fps (for 1-channel sensor output)	18 fps (for 4-channel sensor output) 9 fps (for 2-channel sensor output) 5 fps (for 1-channel sensor output)
Minimum illumination		0.5 lx (Iris: F1.4, Gain: 18 dB, Shutter: 1/27 sec)	0.5 lx (Iris: F1.4, Gain: 18 dB, Shutter: 1/18 sec)
Sensitivity		F8 (400 lx, Gain: 0 dB)	F8 (400 lx, Gain: 0 dB)
SNR		More than 50 dB (Lens close, Gain: 0 dB, 8 bits)	
Gain		Auto, Manual 0 dB to 18 dB	
Shutter speed		Auto, Manual: 2 to 1/100,000 sec	
Reference video output level		235 steps (for 8-bit)/3,760 steps (for 12-bit)	
Reference pedestal level		15 steps (for 8-bit)/240 steps (for 12-bit)	
Camera function			
Readout mode		Normal, binning (2 × 1, 1 × 2, 2 × 2), partial scan	
Readout function		LUT (binarization, gamma (variable setting), test pattern (black and white chart), 3 × 3 filter	
Synchronization		inside/ outside (hardware trigger, software trigger)	
Trigger mode		OFF (free run), ON (edge detection, trigger pulse width), special trigger (bulk trigger, sequential trigger)	
User channel (User set)		16 channel	
User memory		32 kilobytes + 64 bytes × 16 ch	
Partial scan	W (pixel)	16 - 2758	16 - 3388
	H (line)	4 - 2208	4 - 2712
GPO		EXPOSURE/strobe/LVAL/FVAL/sensor readout/trigger through/pulse signal generation/user defined 1 to 4 (output switching)	
Others		Shading correction, defect correction, temperature readout, sensor tap switching	
Interface			
Video output		digital Mono, 8, 10, 12 bit (factory setting 8 bit)	
Digital interface		LVDS	
Camera standard		Base Configuration, CameraLink® Version 1.2 standard	
Output data clock		sensor tap 1ch 54 MHz (1 tap) /27 MHz (2 tap) 2ch 84 MHz (1 tap) /42 MHz (2 tap) 4ch — /84 MHz (2 tap)	
Digital I/O		TTL IN (×1), TTL IN/OUT (×2), ISO IN (×1), ISO OUT (×2)	

	XCL-S600	XCL-S900
General		
Lens mount	C-mount	
Flange focal length	17.526 mm (23/32 inch)	
External power	DC +12 V (10.5 V to 15.0 V: DC IN connector)	
Power consumption	6 W	
Operating temperature	-10 °C to +45 °C	
Performance guarantee temperature	0 °C to 40 °C	
Storage temperature	-30 °C to +60 °C	
Operating relative humidity	20% to 80% (no condensation)	
Storage relative humidity	20% to 95% (no condensation)	
Vibration resistance	10 G (20 Hz to 200 Hz)	
Shock resistance	70 G	
MTBF	Approx. 8.7 years	
External dimension (W × H × D)	50 × 50 × 57.5 mm (2 × 2 × 2 3/8 inches) (excluding protrusions)	
Mass	Approx. 181 g (6.4 oz)	
Standard	UL60950-1, FCC Class A, CSA C22.2-No.1, IC Class A Digital Device, CE: EN61326 (Class A), AS EMC: EN61326, VCCI Class A, KCC	
Accessories	Lens mount cap (1), Operating Instructions (1)	

Color model

	XCL-S600C	XCL-S900C
Camera		
Picture size	6 megabytes	9 megabytes
Video output	1/1 type PS IT CCD	1/1 type PS IT CCD
Valid pixels (H × V)	2,758 × 2,208	3,388 × 2,712
Cell size (H × V)	4.54 μm × 4.54 μm	3.69 μm × 3.69 μm
Standard video output pixels (H × V)	2,752 × 2,200	3,384 × 2,704
Color filter	Original color mosaic	
Standard frame rate	27 fps (for 4-channel sensor output) 13 fps(for 2-channel sensor output) 7.5 fps (for 1-channel sensor output)	18 fps (for 4-channel sensor output) 9 fps (for 2-channel sensor output) 5 fps (for 1-channel sensor output)
Minimum illumination	6 lx (Iris: F1.4, Gain: 18 dB, Shutter: 1/27 sec)	6 lx (Iris: F1.4, Gain: 18 dB, Shutter: 1/18 sec)
Sensitivity	F8 (2000 lx, Gain: 0 dB)	F8 (2000 lx, Gain: 0 dB)
SNR	More than 50 dB (Lens close, Gain: 0 dB, 8 bits)	
Gain	Auto, Manual 0 dB to 18 dB	
Shutter speed	Auto, Manual: 2 to 1/100,000 sec	
White balance	Manual, One push	
Reference video output level	3,760 step (for 12-bit)	
Reference pedestal level	240 step (for 12-bit)	

		XCL-S600C	XCL-S900C
Camera function			
Read out mode		Normal, partial scan	
Read out function		LUT (binarization, gamma (variable setting)), test pattern (black and white chart), 3 × 3 filter, color matrix (for RGB output)	
Synchronization		OFF (free fun), ON (edge detection), Special trigger (bulk trigger, Sequential trigger)	
Trigger mode		Edge detection, exposure by trigger pulse width, normal trigger, trigger delay, bulk trigger, sequential trigger, trigger range	
User channel (User set)		16 channel	
User memory		32 kilobytes + 64 bytes × 16 ch	
Partial scan	W (pixel)	16 - 2758	16 - 3388
	H (line)	4 - 2208	4 - 2712
GPO		EXPOSURE/strobe/LVAL/FVAL/sensor readout/trigger through/pulse signal generation/user defined 1 to 4 (output switching)	
Others		Shading correction, defect correction, temperature readout, sensor tap switching	
Interface			
Video output		digital Raw, 8, 10, 12 bit (factory setting: 8 bit), RGB 24 bit	
Digital interface		LVDS	
Camera standard		Base Configuration, CameraLink® Version 1.2 standard	
Output data clock		Sensor tap 1ch 54 MHz (1tap) /27 MHz (2tap) 2ch 84 MHz (1tap) /42 MHz (2tap) 4ch — /84 MHz (2tap)	
Digital I/O		TTL IN (2×), TTL OUT (2×)	
General			
Lens mount		C-mount	
Flange focal length		17.526 mm (23/32 inch)	
External power		DC +12 V (10.5 V to 15.0 V)	
Power consumption		6 W	
Operating temperature		-10 °C to +45 °C	
Performance guarantee temperature		0 °C to 40 °C	
Storage temperature		-30 °C to +60 °C	
Operating relative humidity		20% to 80% (no condensation)	
Storage relative humidity		20% to 95% (no condensation)	
Vibration resistance		10 G (20 Hz to 200 Hz)	
Shock resistance		70 G	
MTBF		Approx. 8.7 years	
External dimension (W × H × D)		50 × 50 × 57.5 mm (2 × 2 × 2 3/8 inches) (excluding protrusions)	
Mass		Approx. 181 g (6.4 oz)	
Standard		UL60950-1, FCC Class A, CSA C22.2-No.1, IC Class A Digital Device, CE: EN61326 (Class A), AS EMC: EN61326, VCCI Class A, KCC	
Accessories		Lens mount cap (1), Operating Instructions (1)	

Design and specifications are subject to change without notice.


IMPORTANT

The nameplate is located on the bottom.


Spectral Sensitivity Characteristics (Typical Values)

Monochrome model

XCL-S600 (excluding lens and light source characteristics)




XCL-S900 (excluding lens and light source characteristics)




Color model


XCL-S600C (excluding lens and light source characteristics)



XCL-S900C (excluding lens and light source characteristics)



Dimensions



Sony reserves the right to change specifications of the products and discontinue products without notice.
Technical information contained herein is for reference only and does not convey any license by any implication or otherwise under any intellectual property right or other right of Sony or third parties.
Sony cannot assume responsibility for any right infringements arising out of the use of this information.